

E-Z Haul Carts Assemble Instructions

“Utility Cart” 8.0 Cubic Feet

Contents:

- (1) Front Tub Frame
- (1) Back Tub Frame
- (2) Leg Rails
- (1) Mushroom Shaped Handle
- (1) Saddle Axle Housing Assembly
- (2) Tub Clamps
- (2) Wheels
- (1) Tub
- (2) 1 ½” Hex Bolts
- (12) Lock Nuts
- (20) ¼” Washers
- (2) 1 ¾” Hex Bolts
- (2) ¾” Washers
- (2) Cotter Pins
- (2) 1 ¾” Slotted Bolts (for use with tub clamps)
- (2) Wing Nuts

Assembly: (see pictures)

1. Place Front Tub Frame & Back Tub Frame upright
2. Connect Saddle Axle Housing, Leg Rails, to the Tub Rails (tighten lightly)
3. Insert and secure Mushroom Shaped Handle over open ends of Leg Rails
4. After all frame parts are connected fully tighten all bolts.
5. Lay frame on side and place Axle through Saddle Axle Housing
6. Place one wheel on Axle and follow with a washer; place Cotter Pin through hole in end of Axle and using pliers bend the open end of the pin to keep in place. Repeat with other wheel.
7. Place the Tub in the Frame.
8. Place Tub Clamp over holes and place Slotted Bolt through and secure with Wing Nut (leave loose). Repeat with second clamp. (Fully tighten both)
9. Attach Skid Plates to bottom of Leg Rails.
10. Enjoy your E-Z Haul Cart!

E-Z Haul Carts
(800) 782-8261

Utility Cart 8.0 Cubic Feet

